



## Using Release® Adhesive & Sealant Remover and “The Stick” to Remove Protective Film

Many Recreational Vehicles (RVs) have a protective adhesive film that protects the exterior gel coat/clear coat finish. They can be tedious to remove without Release®.

Release® Adhesive & Sealant Remover breaks the bond of protective film adhesives. “The Stick” is a hand tool that is the perfect complement to Release®. Step-by-step instructions on how to remove protective film using these products follow.

### Tools Required

“The Stick”

Stock #1813

Release® Adhesive &  
Sealant Remover

16 fl. oz.

Stock #12288

### Instructions

1. Starting in an upper corner, spray Release® on the edge of the film. Let the Release® begin to work and use “The Stick” to slowly and carefully peel a corner of the film. Once you have peeled up enough of the film to allow you to get a grip on it, spray again where the film meets the coach building a pocket, and slowly pull the film using a rocking motion. A side to side motion works best, first pulling one side and then the other, spraying as needed. If you pull too quickly, you can break the film and/or leave glue behind. Slow and steady is the key. 🐢
2. You will know when it is time for more Release® as the film will become harder to pull. Use “The Stick” as needed if the film breaks and you need to peel enough up to get a new grip on it.
3. If you find you are leaving glue behind, you are either not using enough Release® or you are trying to go too fast.

### Additional uses of Release® Adhesive & Sealant Remover

Now in its second generation, Release® Adhesive & Sealant Remover is excellent for the removal of adhesives of protective film, decals, stickers, tapes, and labels. The product can also be used on most carpeted, vinyl, and painted surfaces. Paired with “The Stick” scraping tool, Release® removes adhesives with ease.